


SHEAFFER'S


Skripsert FOUNTAIN PEN

FILLING INSTRUCTIONS



1 Pull off cap.

2 Grip point holder between chrome band and pen point. Unscrew barrel.



3 Insert Skrip cartridge in barrel, **EITHER END FIRST**

4 Grip point holder as in step No. 2 and replace barrel by screwing up tightly.

5 Hold pen in writing position for a few seconds. Then if pen does not write, unscrew barrel and squeeze plastic cartridge gently. (This should only be necessary first time new pen is filled.)

6 To refill, merely replace used cartridge.

7 **USE ONLY SHEAFFER'S SKRIP CARTRIDGES IN YOUR 'SKRIPSERT' FOUNTAIN PEN**

a product of

W. A. SHEAFFER PEN COMPANY

Fort Madison, Iowa - U.S.A.

Printed in U.S.A.

EMERGENCY REFILLING
FOR YOUR *Skripsert* FOUNTAIN PEN

If new cartridge is not readily available, an empty cartridge may be partially filled by unscrewing the barrel, immersing writing point in available ink supply and lightly squeezing empty cartridge. If this emergency filling is necessary, *be sure* excess ink is drained from point with tissue or other soft absorbent material.

HOW TO FILL YOUR

SHEAFFER'S
Skriptiter
BALLPOINT




To replace Skriptiter ballpoint cartridge, unscrew cap from barrel, then remove used cartridge. Reassemble with new cartridge by reversing process.

**USE ONLY SHEAFFER'S
REFILL UNITS**

HOW TO FILL YOUR

SHEAFFER'S
PENCIL



Turn cap clockwise until metal rod appears at point. Then turn back completely . . . insert lead. Press gently against hard surface to engage clutch mechanism.

**ALWAYS USE FINELINE
LEADS AND ERASERS**

Guarantee

For a period of one year from date of purchase, the W. A. Sheaffer Pen Company guarantees to replace without charge any parts which upon factory inspection are found to be defective. In such cases, the only charge made is for transportation and insurance.